

On-site Wastewater Management
Training Course

Passive Dosing Systems

Siphons and Flouts,
Low Pressure Effluent
Distribution Systems

Centre for Environmental Training cet

Siphons

- Transform low or variable flows into regular doses
- Suitable for pressurising manifolds and drainfields
- Have no moving parts
- Require no electricity
- Technology over 100 years old
- Require understanding to ensure appropriate use and operation


Centre for Environmental Training cet

Various Siphons Available

- Stafford siphon
- Flowking
- ecoteam Surgeflow
- Ubi Aqua by ecoteam
- Orenco




Source: Airis Wastewater Clinic



Source: Ubi Aqua

Centre for Environmental Training cet


Dosing Siphon Anatomy



Source: D Stafford


Centre for Environmental Training cet

Siphon Cycle



trap primed







Centre for Environmental Training cet




start and end of cycle

Vented to atmosphere


Centre for Environmental Training cet




Siphon Optimisation




- An outlet filter must be fitted to the septic tank
- Bell:trap volume approximately 3:1
- Bell diameter:trap pipe diameter approximately 3:1
- Deep trap easier to trigger
- Shallow traps need to be driven with high inflow rates
- Balance tube required for reliable resetting
- Calibration of relationship of balance tube ends important

Centre for Environmental Training 


Siphon Operation



Source: Aris Wastewater Clinic

Centre for Environmental Training 


Use



Applications



- Domestic waste water treatment system, Martinsville, NSW
- One of two dosing siphons in the system

Centre for Environmental Training 

Applications



- Cheese making waste treatment, Nimbin, NSW
- Doses a drainfield manifold with limited fall



Applications



Greywater septic tank to dosing chamber, near Nimbin, NSW

Centre for Environmental Training 

Applications




Testing squirt height and uniformity, near Nimbin

Centre for Environmental Training cet

Flout


- Single flout
- Double flout
- Low drawdown possible with larger dose volume



- <https://rissyplastics.com/flout-systems/>
- <https://www.onsiteisite.com/the-flout-dosing-device/>

Centre for Environmental Training cet

Flout



Centre for Environmental Training cet

Flout dosing a sand filter



Centre for Environmental Training cet

Flout



Low Pressure Effluent Distribution (LPED) Systems

EDRS (EPA, 2024; Section 2.4.3.2) and (AS/NZS1547:2012; Section M5)

LPED Irrigation

- Shallow subsurface irrigation of effluent into topsoil through low pressure effluent distribution (LPED) lines

LPED line

- A pressure line perforated with drilled squirt holes and nestled in a distribution line

Centre for Environmental Training cet

LPED Irrigation

- Suitable for both Primary (with outlet filter) and Secondary effluent
- On moderate to flat slopes up to 10-15%
- Distributed into shallow trenches 200mm wide by 200mm deep, excavated in good quality topsoil
- Minimum 250mm topsoil below application depth required for Category 5 or 6 soils

LPED Irrigation

- Require dosed flow using pressure (pump) or low-pressure (siphon or Flout). Not gravity fed
- Ensures even distribution along whole LPED trench, avoids spot loading of slotted pipe
- Facilitates hydraulic and nutrient uptake by transpiration and seepage
- Use sequencing valve to alternate loading of lines (pump only)

LPED Irrigation

- Minimum 1,000mm spacing between LPED trenches
- Trenches constructed along the contour on sloping ground (max 27% gradient)
- All LPED systems should incorporate capacity for flushing (as per Figure M3)
- LPED require careful hydraulic design on sloping sites


DIRs for LPED

Soil Category	Soil texture	Structure	Drip and spray irrigation	LPED irrigation
DIR (mm/day)				
1	Gravel and sand	--	5	Not advised
2	Sandy loam	All	5	4
3	Loam	All	4	3.5
4	Clay loam	All	3.5	3
5	Light clay	All	3	2.5
6	Medium to heavy clay	--	2	Not advised



LPED Irrigation


- Pressure line 25-40mm PVC with 3-6mm drilled holes at appropriate spacing for even distribution along whole length
- Clean water test to observe even squirt height before covering
- Distribution line wrapped (sleeved) in Ag-pipe or slotted 100mm PVC

LPED Irrigation



LPED Irrigation



Centre for Environmental Training 

References

- The Flout Dosing Device. A device for gravity dosing of effluent or stormwater.
<https://www.onsiteisite.com/the-flout-dosing-device/>
- Arris Wastewater Clinic automatic dosing siphons
<https://wwwclinic.com.au/sample-page/automatic-dosing-siphons/>

Centre for Environmental Training 